



CT-4100A, CT-4100B, CT4100C, CT4100D, CT-4100E Elite Direct Attach Hutch Access

20|64, 24|74 Full Open, 24|74 Offset, 35|85 Full Open & 35|85 Offset
Assembly Instructions



CT-4100E Elite Direct Attach Hutch Access (20|64, Full Open) Kit Bill of Material:

Item	Item Number	Description	Qty
1	CT-4100	Frame, Hutch Front Gate	1
2	CT-4105	Bracket, 20 64 Center	1
3	CT-9006	Gate	1
4	CT-9008	Gate Latch	1
5	CT-HDWE-042	Upper Loop Hardware	3
6	CT-HDWE-044	Hinge Hardware	1

CT-4100B Elite Direct Attach Hutch Access (24|74, Offset) Kit Bill of Material:

Item	Item Number	Description	Qty
1	CT-4100	Frame, Hutch Front Gate	1
2	CT-4103	Bracket, 24 74 Offset	1
3	CT-4102	Bracket, 24 74 Offset & 35 85	1
4	CT-9006	Gate	1
5	CT-9008	Gate Latch	1
6	CT-HDWE-042	Upper Loop Hardware	3
7	CT-HDWE-044	Hinge Hardware	1

CT-4100A Elite Direct Attach Hutch Access (24|74, Full Open) Kit Bill of Material:

Item	Item Number	Description	Qty
1	CT-4100	Frame, Hutch Front Gate	1
2	CT-4103	Bracket, 24 74 Center & 35 85	1
3	CT-9006	Gate	1
4	CT-9008	Gate Latch	1
5	CT-HDWE-042	Upper Loop Hardware	3
6	CT-HDWE-044	Hinge Hardware	1



CT-4100D Elite Direct Attach Hutch Access (35|85, Offset) Kit Bill of Material:

Item	Item Number	Description	Qty
1	CT-4100	Frame, Hutch Front Gate	1
2	CT-4103	Bracket, 24 74 Center & 35 85	1
3	CT-4104	Bracket, 35 85 Offset	1
4	CT-9006	Gate	1
5	CT-9008	Gate Latch	1
6	CT-HDWE-042	Upper Loop Hardware	3
7	CT-HDWE-044	Hinge Hardware	1

CT-4100C Elite Direct Attach Hutch Access (35|85, Full Open) Kit Bill of Material:

Item	Item Number	Description	Qty
1	CT-4100	Frame, Hutch Front Gate	1
2	CT-4102	Bracket, 24 74 Offset & 35 85	1
3	CT-9006	Gate	1
4	CT-9008	Gate Latch	1
5	CT-HDWE-042	Upper Loop Hardware	3
6	CT-HDWE-044	Hinge Hardware	1

Tools Needed:

1. 3/8" Drill Bit
2. 1/2 in (12.7 mm) Deep Socket with Ratchet
3. 1/2 in (12.7 mm) Wrench

Installation Instructions:

Step 1: Center frame on to front opening of hutch: Bottom steel angle slides over the plastic threshold.

Step 2: Bolt the side brackets to the frame: Depending on the version of hutch you have (left entry, right entry, or full open) will determine which bracket goes on the right and the left.

Step 3: Adjust the side bracket: Bracket should be nearly horizontal. Mark the hutch to drill the holes for mounting. Using a 3/8" drill bit, drill holes.

Step 4: Secure side brackets: Only 1 bolt is needed per bracket. Tighten in place.

Step 5: Mark bottom mounting holes: Once the side brackets are installed, mark the hutch for the bottom mounting holes. This helps secure the frame to the hutch.

Step 6: Secure frame: Using bolts, fasten frame in place to bottom of hutch.

Step 7: Attach latch: Using latch hardware, fasten latch to frame.

Step 8: Hang gate: Start by guiding top hinge on gate through the top hole on frame. Once hinge is in place, follow with bottom hinge.

